



TREM SRL - ITALY - WWW.TREM.NET - INFO@TREM.NET

## CARRELLO ANTERIORE PER TRASPORTO CANOTTI PNEUMATICI

### ISTRUZIONI DI MONTAGGIO ED UTILIZZO

- 1 - Applicare le ruote come da disegno 4.
- 2 - Inserire la maniglia anteriore al canotto come da disegno 1.
- 3 - Premere con un piede sull'assale facendo leva sulla impugnatura come da disegno 2.
- 4 - Il disegno 3 illustra il carrello in fase di trasporto.

## CHARIOT ANTERIEUR POUR LE TRANSPORT DES BATEAUX PNEUMATIQUES

### INSTRUCTIONS POUR LE MONTAGE ET UTILISATION

- 1 - Monter les roues, d'après le dessin explosé 4.
- 2 - Joindre la poignée antérieure du bateau pneumatique, d'après le dessin 1.
- 3 - Appuyer avec un pied sur l'axial en faisant levier sur la poignée, d'après le dessin 2.
- 4 - Le dessin 3 montre le chariot en phase de transport.

## FRONT TROLLEY FOR THE TRANSPORT OF RUBBER BOATS

### ASSEMBLING AND USE INSTRUCTIONS

- 1 - Mount wheels as per exploded drawing 4.
- 2 - Join the front handle to the rubber boat, as per drawing 1.
- 3 - Press with a foot on the axle, keeping lever on the handle, as per drawing 2.
- 4 - Drawing 3 shows the trolley during the transport.

**ART. 00836110**

**ART. 00836260**

